

U-Blocks

Using U-blocks the outer measurement (A-measurement) can be changed on both Standard blocks and AddBlocks. The edges lock the blocks into each other; considerably simplifying assembly.


U-blocks are available in five sizes: a standard 20/4 block can, for example, be transformed into the following sizes: 30/4, 40/4, 60/4, 90/4 and 120/4.





available once you start using U-Blocks.		
Standard spare	Size available	Use the following blocks
20/0	30/0	U-30 and 20/0
	40/0	U-40,U-30 and 20/0
	60/0	U-60,U-40,U-30 and 20/0
	90/0	U-90,U-60,U-40,U-30 and 20/0
	120/0	U-120,U-90,U-60,U-40,U-30 and 20/0
30/0	40/0	U-40 and 30/0
	60/0	U-60,U-40 and 30/0
	90/0	U-90,U-60,U-40 and 30/0
	120/0	U-120,U-90,U-60,U-40 and 30/0
40/0	60/0	U-60 and 40/0
	90/0	U-90,U-60 and 40/0
	120/0	U-120,U-90,U-60 and 40/0
60/0	90/0	U-90 and 60/0
	120/0	U-120,U-90 and 60/0
90/0	120/0	U-120 and 90/0

The total number of Spare blocks



Using U-Blocks

