

# MOUNTING AND MAINTENANCE INSTRUCTION




ITALO\_IM\_ENG - Rev.09 of 15/07/15



 $M8\;screws + split\;washer\;and\;plain\;washer$ 

Set screw wrench: 6mm Twisting moment: 10Nm



### **MOUNTING AND MAINTENANCE INSTRUCTION**

#### Post-top or bracket mounting

ITALO 1 is equipped with an universal attachment (post-top or bracket mounting) according to the ordered version:

- Attachment Ø33-60mm.
- Attachment Ø60-76mm.

Place correctly the attachment as indicated in Pic. 5A (Post-top) or in Pic. 5B (Bracket).

Fix the attachment to the luminaire with the two M8 screws as indicated in Pic. 2. Possible to tilt:


Post-top mounting: 0°, +5°, +10°, +15°, +20°
Bracket mounting: 0°, -5°, -10°, -15°, -20°


Use the proper sign as indicated in Pic. 3A and 3B.


The regulation of the luminaire can be done loosing the two screws (Pic. 2).

Fix the attachment to the post-top or to the bracket as indicated in Pic. 4.

To avoid any possible unscrewing of grub screws, two M8 nuts have to be tightened on the grub screws as indicate in Pic. 4.









# MOUNTING AND MAINTENANCE INSTRUCTION




TALO\_IM\_ENG - Rev.09 of 15/07/15 Page 2 of 4


#### Electrical line connection


To gain access to the electrical line, unlock the closing hook (A - Pic. 6) and lift the upper frame up to the action of the hinge (Pic. 7)


- **Luminaire with cable gland**: follow the directions in Pic. 8. Is not necessary tight the external sheet of the mains cable to the cable holder of the on-load switch. However the cable holder has to be tight to maintain in position the two cables.
- **Luminaire with membrane**: follow the directions in Pic. 9. Is strictly necessary tight the external sheet of the mains cable to the cable holder of the on-load switch.

In case the luminaire is equipped with PLM device, before close the luminaire, annotate the serial number of the device.



















## **MOUNTING AND MAINTENANCE** INSTRUCTION




#### Luminaire closure

To close the luminaire, follow the directive from Pic. 10 to Pic. 12.








upper frame

## LED module extraction

- 1) Disconnect the LED connector (C);
- 2) Loosen the screws (E);
- **LED** 3) Extract the module.

### LED module repositioning

- 1) Replace in the original position the **LED** module;
- 2) Tighten the screws (E);
- 3) Connect the **LED** connector (C).



## Gear tray extraction

- 1) Disconnect the mains connector (B);
- 2) Disconnect the **LED** connector (C);
- 3) Loosen the 2 screws (D);
- 4) Extract the gear tray.

## Gear tray repositioning

- 1) Replace in the original position the gear tray;
- 2) Tighten the 2 screws (D);
- 3) Connect the LED connector (C);
- 4) Connect the mains connector (B).

#### SPD MAINTENANCE

The protection device is equipped with system that excludes power supply at the end of life of the luminaire. If the luminaires switches-off when the system is still fed, the activity of the protection device should be checked looking at signaling LED.

To check this, use the appropriate tool asked to AEC Illuminazione.


















**5** Made in Italy




ITALO 1 luminaire is classified under "EXEMPT GROUP" according to photobiologycal safety standard IEC/EN 62471.

# **NO RISK**

for the operators and end users.



Side area:	$0.06\text{m}^2$
Base area:	$0.18m^2$
Form factor:	1.2
Max height of installation:	15m
Ta	35°C
Use	Indoor / Outdoor
ITALO 1 1M	$5.2$ kg $\div$ $5.9$ kg
ITALO 1 2M	$5.3$ kg $\div$ $6.7$ kg
ITALO 1 3M	6.0kg ÷ 6.9kg
ITALO 1 4M	6.1kg ÷ 7.0kg







#### INFORMATION TO THE CUSTOMERS

Directive 2002/96/EC (Waste Electrical and Electronic Equipment - WEEE): information for users.

This product complies with EU Directive 2002/95/EC. The crossed-out wastebasket symbol on the appliance means that at the end of its useful lifespan, the product must be disposed of separately from ordinary household wastes. The user is responsible for delivering the appliance to an appropriate collection facility at the end of its useful lifespan. Appropriate separate collection to permit recycling, treatment and environmentally compatible disposal helps prevent negative impact on the environment and human health and promotes recycling of the materials making up the product. For more information on available collection facilities, contact your local waste collection service.





F	Fuse 250Vac 10A (provide the fuse externally if not present into the luminaire)	PD	Protection device
CN	Connector	PSU	Power Supply
S	On-load switch	CD	Control device

#### NOTE

- The luminaire can be installed close to flammable surfaces. a)
- Class II luminaires must be installed in such a way that it is impossible for any exposed metal part to come in contact with electrical b) components.
- The device has developed in compliance with the current standards; it is necessary that the installation is done properly, according with the instructions supplied.
- The present instruction paper has to be kept for any future maintenance operation on the luminaire. Non compliance with the above will automatically release AEC Illuminazione Srl from any responsibility.