

Ultrathin Touch Slide RF Remote Controller

Scanstrip REMOTE DIM/CCT/RGBW Art.nr. 71155 / 71156 / 71157-15

ANETA
PROFESSIONAL

Touch color slide/1-3 color/Wireless remote 30m distance/CR2032 battery/Magnet stuck fix



CE RoHS LVD RED

Features

- Apply to single color, dual color or RGBW LED controller.
- Ultra sensitive dimming/color adjustment touch slide.
- Each remote can match one or more receivers.
- CR2032 battery powered.
- Operate with LED indicator light.
- Magnet on the back which can be easily stuck on back holder or any metal surfaces.

Technical Parameters

Input and Output	
Output signal	RF(2.4GHz)
Working voltage	3VDC(CR2032)
Working current	<5mA
Standby current	<10μA
Standby time	1 year
Remote distance	30m(Barrier-free space)

Environment	
Operation temperature	Ta:-30°C ~ +55°C
IP rating	IP20


Safety and EMC	
EMC standard (EMC)	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-17 V3.2.4
Safety standard (VDE)	EN 62368-1:2020+A11:2020
Radio Equipment (RED)	ETSI EN 300 328 V2.2.2
Certification	CE, EMC, LVD, RED

Warranty	
Warranty	5 years

Weight	
Net weight	24g
Gross weight	64g

Scanstrip REMOTE - Ultrathin Touch Slide RF Remote Controller

Mechanical Structures and Installations



To fix the remote, three options are offered for selection:

- Option 1: stick the remote on any metal surfaces directly.
- Option 2: fix the remote back holder on the wall with two screws.
- Option 3: adhere the remote back holder to the wall using glue.

Match Remote Control (two match ways)

End user can choose the suitable match/delete ways. Two options are offered for selection:

Use the controller's Match key

Match:
Short press match key,
immediately press on/off key on the remote.
The LED indicator fast flash a few times
means match is successful.

Delete:
Press and hold match key for 5s to delete all match,
The LED indicator fast flash a few times
means all matched remotes were deleted.


Use Power Restart

Match:
Switch off the power, then switch on power, repeat again.
Immediately short press on/off key 3 times on the remote.
The light blinks 3 times means match is successful.


Delete:
Switch off the power, then switch on power, repeat again.
Immediately short press on/off key 5 times on the remote.
The light blinks 5 times means all matched remotes were
deleted.

Key function


• DIM - 1 zone dimming remote



• CCT - 1 zone CCT remote



• RGBW - 1 zone RGB remote



1. Short press for On/Off.
2. Press and hold 1-6s for RGB brightness dimming.
3. Fast press 2 times for shift between RGB, WW and RGBW mode. In RGB or RGB+WW mode, touch slide to change RGB color. In WW mode, touch slide to change white brightness.

Safety information

1. Read all instructions carefully before you begin this installation.
2. When installing battery, pay attention to the battery positive and negative polarity.
A long time without the remote control, remove the battery.
When remote distance becomes smaller and insensitive, replace the battery.
3. If no response from the receiver, please rematch the remote.
4. Gently handle remote, beware of falling.
5. For indoor and dry location use only.