


SACE Tmax XT

- PB - Separatori di fase XT1-XT2-XT3-XT4
- PB - Phase barriers XT1-XT2-XT3-XT4
- PB - Trennwände zwischen den Phasen XT1-XT2-XT3-XT4
- PB - Séparateurs de phase XT1-XT2-XT3-XT4
- PB - Separadores de fase XT1-XT2-XT3-XT4
- PB - 相间隔板XT1-XT2-XT3-XT4


XT1-XT2-XT3-XT4



	III	IV	III	IV	III	IV
XT1	4	6	4	6	4	6
XT3	4	6	4	6	4	6


	III	IV	III	IV	III	IV
XT2	4	6	4	6	4	6
XT4	4	6	4	6	4	6

	Rear	III	IV
XT1	4	6	
XT2	4	6	
XT3	4	6	
XT4	4	6	




A

XT1 - XT3




B

XT1 - XT3




C

XT1 XT3/EF




D

XT1 - XT3/ F / ES




E

XT1 - XT3/ P




F

XT1 - XT3




G

XT1 - XT3/ Fc CuAl/ P




H

XT1 - XT3




I

ONLY FOR XT2 F- XT4 F




J

XT2 - XT4




K

XT2 - XT4/EF



L

XT2 - XT4/ES





M

XT2 - XT4

N

XT2 - XT4





O

XT2 - XT4

P

XT2 - XT4



Q

XT1 - XT2 - XT3 - XT4 / P

