


Spacer



Spacer for use in profiles, type TP.
For static reasons, the spacer is always used to prevent the profile from deforming when the fastening bolts are tightened.

Type	Pack. pcs	Weight kg/100 pcs.	Item No.
DS 4 FS	20	3,700	6416551
DS 4 FT	20	3,800	6416586
DS 4 VA4301	10	3,700	6416594

St Steel **V2A** Stainless steel, grade 304

FS Strip-galvanised **FT** Hot-dip galvanised

Dimensions

