



FERRET LITE[®]

Multipurpose Wireless Inspection Camera

User guide and FAQs



WORK SAFER. WORK SMARTER. SMART TOOL. SMART CHOICE.

- Visual inspections
- Cable installations
- Maintenance
- Repair work
- On the job or at home

Welcome to the Ferret Community!
Thank you for choosing the Ferret Pro camera



Share on social    

The Ferret community would love to see how the Ferret is being used on the job or at home and how the Ferret has come to your rescue!

Please share and tag us on social.

Follow us on **@FerretTools**
Official hashtag **#FerretTools**



**Designed and Engineered
in New Zealand by:**

Ferret Tools Limited

**This Ferret camera is covered by
trademarks & pending patents.
Refer [ferrettools.com/ip](https://www.ferrettools.com/ip)**

Ferret Lite

Model CFWF50L

Version 3.0 © 2022

2 yrs Manufacturer's Warranty
www.ferrettools.com

Made in PRC

FERRET LITE FEATURES:



**Built-in WiFi hotspot,
wireless & rechargeable**



**Adjustable bright
white LEDs**



**Free and easy
to use App**



Digital zoom function



720p HD Streaming



**NEW Ferret always up
viewing mode**

The **Ferret Lite** is a general purpose high quality inspection camera that gives eyes inside hard to reach locations. If you like to keep things simple & don't need all the bells and whistles, the Ferret Lite is the ideal cost-effective solution to help on the job or at home.

Ferret Tools: *Creating the future with new thinking and innovation in smart inspection camera technology for Trades & DIY.*

Discover the full Ferret Tools product range at www.ferrettools.com

FERRET LITE SPECIFICATIONS

Model	CFWF50L
Dimensions	3 ¾" long x 1" wide (94mm x 24mm)
Weight	1 ½ ounces (33g)
Camera Resolution	720p HD
Wireless Range	Up to 50' (15m) line of sight
Operating Time	Up to 90 minutes (LEDs on medium brightness setting)
Charge Up Time	~100 minutes
Frequency	2.4GHz
Operating Voltage	5V DC
Operating Temperature	32°F to 95°F (0°C to 35°C)
Storage Temperature	-4°F to 113°F (-20°C to 45°C)

For the full product manual, please refer to www.ferrettools.com/support

FERRET LITE KIT INCLUDES:



Padded
EVA Case



Ferret Lite IP67 rated
camera with back cap
screwed on



Thread adaptors



Turn & click front
hook & magnet



Locking ring



Flexible
Gooseneck

FEATURES OF YOUR FERRET LITE CAMERA

Front View

Camera lens



Adjustable bright
white LEDs

Rear View

Power / Charging
Indication LED



Power switch

USB-C
Charging socket

Rear cap provides
connection for rod, pole
and/or gooseneck




Camera is waterproof
only when the back cap
is screwed on

START USING YOUR FERRET LITE



1 Download the Free Ferret App



Scan the QR Code or search for “Ferret Tools”



Requires iOS
V9.0 or later



Requires Android
V6.0 or later

NOTE: During installation or first use of the app you must give access to the phone or tablet's photo gallery to allow you to save photos and video footage.

2 Connect to your Ferret Camera

Turn on your Ferret camera. The camera power switch is at the back of the camera under the back cap. The camera will take about 2 seconds to boot and power on.



NOTE: The camera is IP67 rated only when the back cap is in place.


On your phone or tablet, turn on WiFi and search for the **Ferret-WiFi-XXXX SSID** in the WiFi list. The Ferret camera has a built in WiFi hotspot, so no other WiFi network is needed.

NOTE: The camera will not link via Bluetooth – it is WiFi only.

3 Enjoy using your Ferret Camera and start saving time & money, working safer & smarter.

FERRET TOOLS APP

Easy to use App
Free on iOS and Android



Your Ferret Tools App has the following buttons:

Help
Screen



Settings
Screen

Capture
photos & videos



Photo & video
Gallery



LED Brightness
Adjustment



Full Screen
Mode



Battery Capacity
Indicator



LED BRIGHTNESS ADJUSTMENT



The LED brightness of your Ferret camera can be adjusted in 2 ways:

1. Tap the LED Brightness Adjustment button to change brightness to one of the three settings:



OFF




NORMAL



FULL

2. Press and hold the LED Brightness Adjustment button. A slider appears below the button which you can slide up or down to adjust LED brightness.



LED Brightness
Slider

DIGITAL ZOOM





Use 2 fingers to use the digital zoom to bring your image closer.





View the images and videos taken in your Ferret Tools Gallery.

You can access or export your Ferret camera photos and videos directly from your **smart device** gallery.



Learn more at www.ferrettools.com to see subscription based cloud storage and exclusive offers. See registration card inside your Ferret kit for details.

APP SETTINGS




To access Settings, tap the Settings button.

If a firmware update for your Ferret camera is available, the “Firmware Update” button will appear on the bottom left of the Settings screen.

The Settings screen allows you to do the following:

1. Set camera and video buttons to appear on the left or right of the main screen in the Ferret Tools App, for easier one handed operation.




Main screen with right hand side-buttons enabled

APP SETTINGS - ALWAYS UP VIEWING MODE



2. Change the Display Mode from Normal (picture orientation reflects camera orientation) to an Always Up Mode – either Round or Full Screen.

In Always Up mode, the picture orientation remains the right way up on the smart device display, regardless of the camera's orientation.



**Always up
round mode**

In this mode no matter which way the Ferret camera is rotated, the image on the App is always the right way up.

FAQs

I can't connect or see the camera when I search on Bluetooth?

The Ferret camera has a built in WiFi hotspot. No other network is needed, and the camera does not connect via Bluetooth.

Can I use the camera underground, underwater or inside a conduit?

No, it will not work underground, underwater or inside a metallic conduit as these scenarios will block the WiFi signal.

How long can I use my Ferret before recharging the battery?

Your Ferret will give you up to 90 minutes of use, with the LEDs on normal brightness, before it needs recharging.

What does the rear LED indicate? The rear LED indicates:

RED = Charging, OFF = Fully Charged, WHITE = Camera ON

I can't connect to WiFi or the WiFi won't stay connected on my Android?

Some Androids don't understand why you want to connect to a WiFi network without Internet. If a warning alert is displayed, check the box to not ask/show again and click OK/Yes.

FAQs

I can connect to the WiFi, but it won't show an image in the App.

Go to Settings -> Data usage -> Cellular data usage and scroll down to find and select the Ferret App. Turn off Background data to prevent the App trying to use cellular data.

When I try to download the App it asks for a password - why?

The Ferret App is free – it will never ask for a password or a code. Your phone sometimes will ask for a password due to your App Store not having a payment method.

Why does my Firmware Update not progress, it stays on 0% progress?

Please try placing your phone into Airplane or Flight mode, turn your phone's WiFi back on (while staying in Airplane mode), restart your Ferret App and Ferret camera, and try the firmware update again.

If your question isn't covered by the FAQs, please refer to www.ferrettools.com/support or email us at support@ferrettools.com



FERRET WARRANTY

**Your FERRET comes with a
2 year replacement warranty.**



**Extend your warranty at
www.ferrettools.com**

In the unlikely event that your FERRET develops a fault within 2 years of purchase, please email support@ferrettools.com, or simply return it your place of purchase with proof of purchase.

Failure due to physical damage, misuse, neglect, improper use or moisture is not covered. The camera has no user serviceable parts inside. Disassembly will void the warranty.

Important Information – Li-Ion Batteries

The Ferret camera contains a Li-Ion battery. For optimal battery life, do not store the camera while the battery is flat, do not store the camera in temperatures of over 35°C (95°F) and if the camera is not being used, top up the charge every 6 months.

 **CAUTION**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and operated with minimum distance 0mm between the radiator & your body.